

		             													
		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
Argus	DC-3200			•											
	DC-3520/3640				•										
	DC-3810GB							•							
	QC-5430		•									•			
BenQ	DC C35/40/50/51/60/62				•										
	DC C500		•		•										
	DC C530		•												
	DC C630		•												
	DC C800		•		•										
	DC E30/40/41/43/53		•												
	DC E520+		•												
	DC E600		•												
	DC S40				•										
	DC X600	•													
	DC-2410			•											
	DC-3410		•												

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW

D-Res 50 AW

D-Res 200AW

D-Res 220 AW

D-Res 240 AW

Canon	DC-10																			
	DC-20																			
	DC21/DC22																			
	DC40																			
	Digital IXUS 430/500																			
	Digital IXUS i/i5																			
	Digital IXUS II/30/40																			
	Elura 100																			
	Elura 2MC/50 Digital/Elura Digital																			
	Elura 85																			
	Elura 90																			
	EOS 5D w/compact zoom																			
	EOS Digital Rebel Xti/400D w/ compact zoom																			
	EOS Rebel XT/350D with kit lens																			
	ES420V/8200/8400V/8600																			
	ES75																			
	G30Hi/35Hi/45Hi																			
	HV10																			
	IXUS 30																			
	IXUS 40																			
	IXUS 50																			
	IXUS 70																			
	IXUS V																			
	MV500/500i/550i/530i/600/600i/630i/650i																			
	MV6i/5/5i/5iMC																			
	MV750i/730i/700i/700																			
	MV800																			
	MV830i																			
	MV850i																			
	MV890																			
	MV900																			
	MV920																			
	MV930/940/950/960																			
	MX100i/150i																			
	MX11																			
	MX250i/200i/200																			
	MX25i/20i																			
	MX2i																			
	MX330i																			
	MX35i/30i																			
	MX430																			
	MX450/460																			
	Optura 10/20																			
	Optura 100MC																			
	Optura 30/40																			
	Optura 300/MVX10i																			
	Optura 50																			
	Optura 60																			
	Optura Pi																			
	Optura Xi/MV3Xi																			
	PowerShot A300/A310																			
	PowerShot A400																			
	PowerShot A410																			
	PowerShot A420																			
	PowerShot A430																			
	PowerShot A510/520																			
	PowerShot A530																			
	PowerShot A540																			
	PowerShot A610																			
	PowerShot A620																			
	PowerShot A630																			
	PowerShot A640																			

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW

D-Res 50 AW

D-Res 200AW



D-Res 220 AW

D-Res 240 AW

PowerShot A700														
PowerShot A710 IS														
PowerShot A80/A85														
PowerShot A95														
PowerShot G5														
PowerShot G6														
PowerShot G7														
PowerShot Pro 1														
PowerShot S110														
PowerShot S2 IS														
PowerShot S3 IS														
PowerShot S60														
PowerShot S70														
PowerShot S80														
PowerShot SD 600/Digital IXUS 60														
PowerShot SD 630/Digital IXUS 65														
PowerShot SD10/SD20/IXY Digital														
PowerShot SD30														
PowerShot SD40/Ixus i7														
PowerShot SD400														
PowerShot SD450														
PowerShot SD550														
PowerShot SD700 IS/Digital IXUS 800 IS														
PowerShot SD800 IS/Digital IXUS 850 IS														
PowerShot SD900 IS/Digital IXUS 900 TI														
V60HI/65HI/75HI														
VC-C4														
ZR10/20/25/30/45MC														
ZR100														
ZR200														
ZR500/600/700														
ZR60/65MC/70MC														
ZR80/85/90														

LOWEPRO D-RES SERIES MATRIX 2007

Still and Digital Video

															
		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
Casio	EXILIM EX-M20U/S20U	•			•										
	EXILIM EX-P600/P700			•											
	EXILIM EX-S100	•													
	EXILIM EX-Z10		•												
	Exilim EX-Z1000				•										
	EXILIM EX-Z1050				•										
	EXILIM EX-Z110		•												
	EXILIM EX-Z120		•												
	EXILIM EX-Z3/Z4/Z4U	•			•										
	EXILIM EX-Z30/Z40/Z40LE	•			•										
	Exilim EX-Z5				•										
	EXILIM EX-Z50/Z55				•										
	EXILIM EX-Z500				•										
	EXILIM EX-Z57/Z750				•										
	Exilim EX-Z60				•										
	Exilim EX-Z600	•													
	Exilim EX-Z7				•										
	Exilim EX-Z70				•										
	EXILIM EX-Z75				•										
	Exilim EX-Z850				•										
	EXILIM Pro EX-P505								•						
	EX-S770	•													
	QV-R3/R4		•		•										
QV-R40/41/51/61/62		•		•											
Concord	1500		•		•										
	3047		•		•										
	4042			•											
	ES 500Z		•												
	Eye-Q 3040		•												
	Eye-Q 3103			•											
	Eye-Q 3341z		•	•											
	Eye-Q 3346Z		•	•											
	Eye-Q 4060z														
	Eye-Q 4360Z				•										
	Eye-Q 5062AF		•	•											
	Eye-Q 5345Z			•											
	Eye-Q 642			•											
	Eye-Q Duo 2000			•											
Contax	i4R		•												
	SL300RT	•													
	TVS			•					•						
	U4R	•													
Creative	DC-Cam 3000/3200z			•											
	202V			•											
DXG	305V			•											
	308														
	321				•										
	409				•										
	503				•										
	528		•												
	568				•										
	568				•										
Epson	L500V		•		•										
	Photo PC L-410		•												
	R-D1									•					

*Availability may vary depending on country and location.



D-Res 4M D-Res 8M D-Res 8 D-Res 8S D-Res 9 D-Res 10 AW D-Res 20 AW D-Res 25 AW D-Res 30 AW D-Res 40 AW D-Res 50 AW D-Res 200AW D-Res 220 AW D-Res 240 AW

		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
Fuji	A-205						•								
	FinePix A330/340		•												
	FinePix A345/A350		•		•										
	FinePix A400/A500/A510				•										
	FinePix A600 Zoom		•												
	FinePix A700		•		•										
	FinePix F30		•												
	FinePix F31fd		•												
	FinePix F470		•		•										
	FinePix F5 Pro w/compact zoom											•			
	FinePix F650 Zoom		•												
	FinePix F710/F810						•								
	FinePix M603				•		•								
	FinePix S5600											•			
	FinePix S6000											•			
	FinePix S6500fd											•			
	FinePix S6900											•			
	FinePix S9000											•			
	FinePix S9100/9600											•			
	FinePix S9500											•			
	FinePix V10		•												
FinePix Z3	•														
FinePix Z5fd	•														
Q1 Digital				•											
Hitachi	DZ-BX37E												•		
	DZ-GX3100E												•		
	DZ-GX3200E												•		
	DZ-GX3300A												•		
	DZ-MV100A/ADO										•	•			•
	DZ-MV200										•				
	DZ-MV230										•				
	DZ-MV230A/270A/270E										•				
	DZ-MV380														•
	DZ-MV550/MV580													•	
	DZ-MV730A													•	
	DZ-MV780A													•	
	M2L													•	
	VMD 865LA/VMH 665/675LA								•				•		
	VMD 875/975LA											•			•
HP	Photosmart C612/612xi														
	Photosmart C618														
	Photosmart E317														
	Photosmart E327		•												
	Photosmart M22/M23		•		•										
	Photosmart M417/M517			•			•								
	Photosmart M425		•												
	Photosmart M525		•												
	Photosmart M527														
	Photosmart R507		•												
	Photosmart R607 SE		•												
	Photosmart R707/R717														
	Photosmart R725														
	Photosmart R727														
	Photosmart R817		•												
Photosmart R818		•													
Photosmart R927		•													
Photosmart R967		•													

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW
















D-Res 50 AW

D-Res 200AW
















D-Res 220 AW

D-Res 240 AW

JVC	Everio GZ-MG26															
	Everio GZ-MG57EK															
	Everio GZ-MG77U															
	GD-D370															
	GR-AX970															
	GR-D200/D23/D53															
	GR-D20EK/D50EK															
	GR-D230															
	GR-D30/70/90US															
	GR-D650															
	GR-D72															
	GR-D73US															
	GR-DF430US															
	GR-DV2000U															
	GR-DV3000U/4000U															
	GR-DV700/DV800U															
	GR-DVL 160/DVL367															
	GR-DVL120U															
	GR-DVL320/520/720															
	GR-DVL725/767/820/920															
	GR-DVM76/96															
	GR-DVP5/P7/P9															
	GR-DX25/77/95/97															
	GR-FX15EK/SX25/FXM39E/SXM49/SXM58															
	GR-SXM240/260/340/740															
	GR-X5															
	GR-XM250US/740U															
	GY-DV500US															
	GZ-M50S															
GZ-MG505HD																
JY-VS5200U																

		             													
		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
Kodak	DX6490/7590/Z7590														
	DX7630/7440														
	Easyshare C300			•											
	Easyshare C310			•											
	Easyshare C330				•										
	Easyshare C340				•										
	Easyshare C360				•										
	Easyshare C433			•											
	Easyshare C443			•											
	Easyshare C530		•												
	Easyshare C533			•											
	Easyshare C643			•											
	Easyshare C663			•											
	Easyshare C743			•											
	Easyshare C875								•						
	Easyshare LS743/753		•				•								
	Easyshare One		•												
	Easyshare P712										•				
	Easyshare P850										•				
	Easyshare P880										•				
	Easyshare Picture Viewer	•													
	Easyshare V530		•												
	Easyshare V550		•												
	Easyshare V570		•												
	Easyshare V603										•				
	Easyshare V610					•									
	Easyshare Z612										•				
	Easyshare Z650										•				
	Easyshare Z700								•						
	Easyshare Z705		•												
	Easyshare Z710										•				
	Easyshare Z730						•								
Easyshare Z740										•					
Easyshare Z760						•									
V550		•													
Konica/Minolta	DiMAGE Z1 Thru Z3 and Z10									•			•		
	DiMAGE Z5/Z20									•					
	Dynax/Maxxum 5d w/short zoom										•				
	Maxxum/Dynax 7D w/short zoom										•				
Kyocera	EZ Digital 1.3														
	Finecam L3V/L4V/L30			•											
	Finecam S3/S3L/S3X/S4/S5/S5R		•		•										
	M400R									•					
	M410R									•					
SL300R/400R	•														
Leica	C-Lux 1		•	•	•										
	Digilux 2										•				
	Digilux 3										•				
	D-Lux 3		•								•				
	M8 w/compact zoom										•				
V-Lux 1										•				•	
Minox	DC-6211		•		•										

*Availability may vary depending on country and location.

		             													
		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
Mustek	DV-3032														
	DV-4000														
	DV-4500														
	G-Smart 350														
	GSmart D35														
	MDC-5000														
MDC-6500z															
Nikon	Coolpix 4500														
	Coolpix 4600/5600														
	Coolpix 4800														
	Coolpix 5700/8700														
	Coolpix 5900/7900														
	Coolpix 7600														
	Coolpix 8400														
	Coolpix 8800														
	Coolpix L1														
	Coolpix L2, L3, L4														
	Coolpix L5														
	Coolpix L6														
	Coolpix P1														
	Coolpix P2														
	Coolpix P3, P4														
	Coolpix S10														
	Coolpix S5														
	Coolpix S6														
	Coolpix S7c														
	Coolpix S8														
	Coolpix S9														
	D100 (Body only)														
	D200 w/compact zoom														
	D2x/D2h (Body only)														
	D40 w/compact zoom														
	D50 w/kit zoom														
	D70 w/kit zoom														
	D80 w/Compact Zoom														

*Availability may vary depending on country and location.



D-Res 4M D-Res 8M D-Res 8 D-Res 8S D-Res 9 D-Res 10 AW D-Res 20 AW D-Res 25 AW D-Res 30 AW D-Res 40 AW D-Res 50 AW D-Res 200AW D-Res 220 AW D-Res 240 AW

Olympus	<ul style="list-style-type: none"> µ digital 600 AZ-1/Ferrari Digital AZ2 C-180 C-300/D-550 Zoom C-350/C-460z/460 Del Sol C-360/C-450/C-460/D-395/D-575/D-580Z C-40 Zoom/D-40 Zoom C-470/D-590 C-50/C-60 C-5000 Zoom C-5060/C-7070 Wide Zoom C-5500/C-55 Sport Zoom C-7000/C-70 C-745/750/760/765 UZ C-765/770 Ultra Zoom D-370L/D-380 D-390 D-425 D-435 D-510 Zoom D-520 D-535z/C-370z D-540/560/565 D-545 D-595 D-630 E-1 w/compact zoom Evolt E-330 w/compact zoom Evolt E-400 w/compact zoom EVOLT E-500 w/compact zoom EVOLT/E-300 w/14-45mm zoom FE-100 FE-110 FE-115 FE-120 FE-130 FE-140 FE-150 FE-170 FE-180 FE-190 FE-200 FE-210 FE-230/240/250 IR-300 IR-500 M:Robe 500 SP-310 SP-320 SP-350 SP-500UZ SP-510UZ SP-550UZ Stylus 1000/Mju Digital 1000 Stylus 700 Stylus 710 Stylus 720SW Stylus 725AW Stylus 730/Mju Digital 730 Stylus 740/Mju Digital 740 Stylus 750/Mju Digital 750 	•	•	•	•									
---------	--	---	---	---	---	--	--	--	--	--	--	--	--	--

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW
















D-Res 50 AW

D-Res 200AW

D-Res 220 AW

D-Res 240 AW

Stylus 760/Mju Digital 760				•									
Stylus 770SW		•		•									
Stylus 800/Mju Digital 800		•		•									
Stylus 810		•		•									
Stylus Verve/Verve S/μ-Mini/Mju Mini Digital		•		•									

		 D-Res 4M	 D-Res 8M	 D-Res 8	 D-Res 8S	 D-Res 9	 D-Res 10 AW	 D-Res 20 AW	 D-Res 25 AW	 D-Res 30 AW	 D-Res 40 AW	 D-Res 50 AW	 D-Res 200AW	 D-Res 220 AW	 D-Res 240 AW
Panasonic	AG-EZ50														
	DMC-FX07		•												
	DMC-LZ3/LZ5		•				•								
	DMC-F1S/F1K		•												
	DMC-F7				•										
	DMC-FX01		•		•										
	DMC-FX1/FX1BS/FX5/FX5BS		•			•									
	DMC-FX2/FX2B/FX7/FX7B		•	•	•										
	DMC-FX3		•												
	DMC-FX50				•										
	DMC-FX8		•												
	DMC-FX9		•												
	DMC-FZ50										•				
	DMC-FZ7								•		•				
	DMC-LC1/LC1B														•
	DMC-LC20					•									
	DMC-LC33/43					•									
	DMC-LC40								•				•		
	DMC-LC5							•					•		
	DMC-LC50/50B/70/70B/80/80B			•			•								
	DMC-LC80		•		•										
	DMC-LZ1/LZ2				•										
	Lumix DMC LS2					•									
	Lumix DMC-FX10/FX12				•										
	Lumix DMC-FX30				•										
	Lumix DMC-L1 w/compact zoom										•				
	Lumix DMC-LS1		•		•										
	Lumix DMC-LS60/LS75		•												
	Lumix DMC-LX1						•								
	Lumix DMC-LX2						•								
	Lumix DMC-LZ6/LZ7				•										
	Lumix DMC-TZ1			•											
	Lumix DMC-TZ2/TZ3			•											
	NV10				•										
	NV-DS29														•
	NV-EX21													•	
	NV-GS1/GS4/GS5													•	
	NV-GS11B/15B										•			•	
	NV-GS120B/200B										•			•	
	NV-GS180													•	
	NV-GS22B/33B/55B													•	
	NV-GS250/400B											•			
	NV-GS27													•	
	NV-GS50													•	
	NV-GS500													•	
	NV-GS70													•	
	NV-GX7										•				
	NV-MX300B														
	PalmCam PV-DC2090						•								
	PalmCam PV-SD4090										•				
	PV-DC152/252/352													•	•
	PV-DV203									•	•			•	
	PV-DV52/102/202/402													•	•
	PV-DV702											•		•	•
	PV-DV952											•		•	•
	PV-GS120/200										•				
	PV-GS150													•	
	PV-GS19													•	
	PV-GS250										•				
	PV-GS300													•	
	PV-GS31													•	
	PV-GS33/GS55													•	

*Availability may vary depending on country and location.



	D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
PV-GS35														
PV-GS50S														
PV-GS55														
PV-GS9/12/14/15														
PV-L352/452/552/652														
PV-L354/454														
PV-SD5000														
SDR-S150														
SV-AS10														
SV-AV100														
SV-AV25														
SV-AV50														
VDR-D150														
VDR-D250														
VDR-D300														
VDR-M30/M50/M50B/M70/M70B														
VDR-M53														
VDR-M75														

PV-GS35														
PV-GS50S														
PV-GS55														
PV-GS9/12/14/15														
PV-L352/452/552/652														
PV-L354/454														
PV-SD5000														
SDR-S150														
SV-AS10														
SV-AV100														
SV-AV25														
SV-AV50														
VDR-D150														
VDR-D250														
VDR-D300														
VDR-M30/M50/M50B/M70/M70B														
VDR-M53														
VDR-M75														

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW

D-Res 50 AW

D-Res 200AW

D-Res 220 AW

D-Res 240 AW

Pentax

- *1st DL w/kit zoom
- *1st DS w/kit zoom
- *st DS 2 w/kit zoom
- EI-3000
- K100D w/compact Zoom
- K110D w/compact zoom
- Optio 30
- Optio 33L/33LF
- Optio 33WR/43WR
- Optio 450/550/555
- Optio 50
- Optio 50L
- Optio 60
- Optio 750Z
- Optio A10
- Optio A20
- Optio E10
- Optio E20
- Optio E30
- Optio L20
- Optio M10
- Optio M20
- Optio M30
- Optio MX/MX4
- Optio S/S4/S4i/S5i
- Optio S30
- Optio S40
- Optio S45
- Optio S50
- Optio S55
- Optio S5n
- Optio S5z
- Optio S6
- Optio S60
- Optio S7
- Optio SV
- Optio T10
- Optio T30
- Optio W10
- Optio W20
- Optio X

•
•
•
•
•

•
•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

Polaroid

- PhotoMAX 320
- PhotoMAX Fun 640 SE
- PhotoMAX PDC 700
- X530

•

•

•
•

•

RCA

- CDS4100
- CDS6300

•
•

•

Ricoh

- Caplio 400G Wide
- Caplio 500G Wide
- Caplio G3/G4
- Caplio GX/GX-8
- Caplio R1v
- Caplio R30
- Caplio R40
- Caplio R5
- Caplio RR30
- Caplio RX

•

•

•

•

•

•

•

•

•

*Availability may vary depending on country and location.

		 D-Res 4M	 D-Res 8M	 D-Res 8	 D-Res 8S	 D-Res 9	 D-Res 10 AW	 D-Res 20 AW	 D-Res 25 AW	 D-Res 30 AW	 D-Res 40 AW	 D-Res 50 AW	 D-Res 200AW	 D-Res 220 AW	 D-Res 240 AW
Rollei	d-24/d-30/d-530 Flex														
	d33/d41														
	da5324		•												
	dp3210														
	dp8300		•												
	dr 5		•												
	Prego da6		•												
	Prego dk4010														
	Prego dp4200														
	Prego dp5300/6300		•		•										
	Prego dp6200		•												
	Prego dp6500		•												
	Prego dr5100			•											

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW

D-Res 50 AW

D-Res 200AW

D-Res 220 AW

D-Res 240 AW

Samsung

Digimax 101/201														
Digimax 200														
Digimax 202														
Digimax 240/420														
Digimax 301														
Digimax 330														
Digimax 340														
Digimax 3500/4500														
Digimax 35MP3														
Digimax 370/430														
Digimax 530														
Digimax 800k														
Digimax A4/A5/A6														
Digimax A40														
Digimax A503														
Digimax A55W														
Digimax A7														
Digimax i5														
Digimax i6 PSP														
Digimax L60														
Digimax L70														
Digimax L85														
Digimax Pro 815														
Digimax S1000														
Digimax S500/S600/S800														
Digimax S700														
Digimax U-CA 3														
Digimax U-CA 401														
Digimax U-CA 501/505														
Digimax U-CA5														
Digimax V5/V6/V50/V70														
Digimax V600/V700														
GX-1L w/compact zoom														
GX-1X w/compact zoom														
NV10														
NV3														
NV7 OPS														
SCD103/D107														
SCD180														
SCD23/27/67/VP-D10														
SCD353														
SCD363														
SCD590														
SCD6040 DuoCam														
SCD6550 DuoCam														
SCL610/650														
SCL700/770, SCW62														
SCL906														
SC-M105														
SC-X105L														
SDC80														
VP-D10														
VP-D101/D103														
VP-D130														
VP-D230/D270i														
VP-D323/D325i														
VP-D361i														
VPD5000i														
VP-D590i														
VP-D6040i/D6050i														
VP-D80i														
VP-D963 WI														

*Availability may vary depending on country and location.

LOWEPRO D-RES SERIES MATRIX 2007

Still and Digital Video

		             													
		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
Sanyo	VP-D97										•				
	VP-W90/VPL700/VPL900										•				
	VPC-C1E Xacti		•												
	VPC-J2 Xacti				•	•									
	DSC-S5 Xacti			•											
	IDC-1000z										•				
	VPC DSC-J1			•											
	VPC-AZ3/VPC-MZ3		•		•										
	VPC-C5 Xacti		•												
	VPC-C6 Xacti		•												
	VPC-J4 Xacti		•												
	VPC-X360														
	Xacti DSC-E6		•		•	•									
Xacti DSC-S6		•		•											
Xacti VPC-HD1												•			
Sharp	VE-CG30U/40U							•							
	VL-AH161U/A111H											•			
	VL-AX1H/AX1U											•			
	VL-MC500H/500U										•			•	
	VL-NZ55U/105U										•			•	
	VL-Z1U/Z3U/Z5H/Z7U										•			•	
VLZ900H										•					
Sipix	SC 2300/3300						•								
















*Availability may vary depending on country and location.



D-Res 4M D-Res 8M D-Res 8 D-Res 8S D-Res 9 D-Res 10 AW D-Res 20 AW D-Res 25 AW D-Res 30 AW D-Res 40 AW D-Res 50 AW D-Res 200AW D-Res 220 AW D-Res 240 AW

Sony	Alpha DSLR-A100 w/compact zoom													
	CCD-TRV108/308/318/608													
	CCD-TRV138													
	CCD-TRV128/328													
	DCR-DVD100/200/300													
	DCR-DVD101/201/301													
	DCR-DVD203E													
	DCR-DVD403E													
	DCR-DVD605													
	DCR-DVD705													
	DCR-DVD92E													
	DCR-HC1000/HC100D													
	DCR-HC14E													
	DCR-HC18E/20/20E/30/30E/40/40E													
	DCR-HC21E													
	DCR-HC42E													
	DCR-HC65/85/85E													
	DCR-HC90E													
	DCR-IP1													
	DCR-IP220													
	DCR-IP5/7BT													
	DCR-IP55													
	DCR-PC1000E													
	DCR-PC101/105													
	DCR-PC105E/106E/107E/109/109E													
	DCR-PC110													
	DCR-PC120													
	DCR-PC330													
	DCR-PC350													
	DCR-PC55													
	DCR-PC8													
	DCR-TRV128/328													
	DCR-TRV140													
	DCR-TRV18/25/27													
	DCR-TRV19/22/33													
	DCR-TRV240/340													
	DCR-TRV250/350/450													
	DCR-TRV260/265/460													
	DCR-TRV38													
	DCR-TRV480													
	DCR-TRV50/80													
	DCR-TRV530													
	DCR-TRV740/840													
	DCR-TRV950													
	DSC-F828													
	DSC-F88													
	DSC-H1, H2, H5													
	DSC-L1													
	DSC-M1													
	DSC-M2													
	DSC-N1													
	DSC-N2													
	DSC-P100/P120													
	DSC-P150/P200													
	DSC-P41/P43													
	DSC-P73/93													
	DSC-R1													
	DSC-S40													
	DSC-S500													
	DSC-S60													
	DSC-S600													
	DSC-S80													

*Availability may vary depending on country and location.

															
		D-Res 4M	D-Res 8M	D-Res 8	D-Res 8S	D-Res 9	D-Res 10 AW	D-Res 20 AW	D-Res 25 AW	D-Res 30 AW	D-Res 40 AW	D-Res 50 AW	D-Res 200AW	D-Res 220 AW	D-Res 240 AW
DSC-S90															
DSC-T10	•														
DSC-T30	•														
DSC-T33	•														
DSC-T5	•														
DSC-T50	•														
DSC-T7	•														
DSC-T9	•														
DSC-V3								•							
DSC-W100		•													
DSC-W15				•											
DSC-W17				•											
DSC-W30, W50, W70		•													
DSC-W5/W7		•	•	•											
DSR-PDX10												•			
HDR-HC1											•	•			
HDR-SR1											•				
HDR-LX1											•				
MVC-CD350								•					•		
MVC-CD500										•					
MVC-FD200										•				•	
Thomson	VMD-160/170									•				•	
	VMD-270									•				•	
Toshiba	PDR-3320						•								
	PDR-3340				•										
	PDR-M700							•							
	PDR-M71/M81														
	PDR-T30		•			•									
UMAX	AstraCam 1800						•								
	Astrapix 610	•	•	•											
	Astrapix A680														
	Powercam Z430			•											

*Availability may vary depending on country and location.



D-Res 4M

D-Res 8M

D-Res 8

D-Res 8S

D-Res 9

D-Res 10 AW

D-Res 20 AW

D-Res 25 AW

D-Res 30 AW

D-Res 40 AW

D-Res 50 AW

D-Res 200AW

D-Res 220 AW

D-Res 240 AW

Vivitar

DVR-210

DVR-310

DVR-410

V3105

V3315

V3345/3355

V3625

V3650

V3695

V3705/3715

V3740

V3750

V3755

V3825

V3826

V5388

V6300

V7310

Vivacam 10

Vivacam 25

Vivacam 3780

Vivacam 4000

Vivacam 4345

Vivacam 5385

Vivacam V2655

Vivacam V2775

Vivacam V3200

Vivacam V3500

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW



D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW



D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW



D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW



D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW



D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW



D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW



*Availability may vary depending on country and location.



D-Res 4M



D-Res 8M



D-Res 8



D-Res 8S



D-Res 9



D-Res 10 AW



D-Res 20 AW



D-Res 25 AW



D-Res 30 AW




D-Res 40 AW



D-Res 50 AW



D-Res 200AW



D-Res 220 AW



D-Res 240 AW