



	Apex 5AW	Apex 10AW	Apex 20AW	Apex 30AW	Apex 60AW	Rezo 10	Rezo 15	Rezo 20	Rezo 30	Rezo 40	Rezo 50	Rezo 60	Rezo TLZ 10	Rezo TLZ 20	D-Res 4M	D-Res 8	D-Res 8s	D-Res 8M	D-Res 9	D-Res 10AW	D-Res 20AW	D-Res 25AW	D-Res 30AW	D-Res 120	D-Res 200 AW	D-Res 220 AW	D-Pods 10	D-Pods 20	D-Pods 30	D-Pods 40	D-Pods 50	Ridge 10	Ridge 20	Ridge 30	Ridge 60	Slider 10	Slider 20	Slider 30				
Canon																																										
Continued																																										
PowerShot A300/A310																																										
PowerShot A400																																										
PowerShot A410																																										
PowerShot A420																																										
PowerShot A430																																										
PowerShot A510/520																																										
PowerShot A530																																										
PowerShot A540																																										
PowerShot A610																																										
PowerShot A620																																										
PowerShot A630																																										
PowerShot A640																																										
PowerShot A700																																										
PowerShot A710 IS																																										
PowerShot A80/A85																																										
PowerShot A95																																										
PowerShot G5																																										
PowerShot G6																																										
PowerShot Pro 1																																										
PowerShot S1 IS																																										
PowerShot S10/S20																																										
PowerShot S110																																										
PowerShot S2 IS																																										
PowerShot S-200/230/400/410/500																																										
PowerShot S3 IS																																										
PowerShot S30/40/45/50/55																																										
PowerShot S-300																																										
PowerShot S-330																																										
PowerShot S60																																										
PowerShot S70																																										
PowerShot S80																																										
PowerShot SD 600/Digital IXUS 60																																										
PowerShot SD 630/Digital IXUS 65																																										
PowerShot SD10/SD20/IXY Digital																																										
PowerShot SD-100/110/200/300																																										
PowerShot SD30																																										
PowerShot SD400																																										
PowerShot SD430 Wireless																																										
PowerShot SD450																																										
PowerShot SD500																																										
PowerShot SD550																																										
PowerShot SD700 IS/Digital IXUS 800 IS																																										
PowerShot SD800 IS/Digital IXUS 850 IS																																										
PowerShot SD900 IS/Digital IXUS Ti																																										
ZR10/20/25/30/45MC																																										
ZR100																																										
ZR200																																										
ZR60/65MC/70MC																																										
ZR-600																																										
ZR80/85/90																																										

*Availability may vary by country or location



		Apex 5AW	Apex 10AW	Apex 20AW	Apex 30AW	Apex 60AW	Rezo 10	Rezo 15	Rezo 20	Rezo 30	Rezo 40	Rezo 50	Rezo 60	Rezo TLZ 10	Rezo TLZ 20	D-Res 4M	D-Res 8	D-Res 8s	D-Res 8M	D-Res 9	D-Res 10AW	D-Res 20AW	D-Res 25AW	D-Res 30AW	D-Res 120	D-Res 200 AW	D-Res 220 AW	D-Pods 10	D-Pods 20	D-Pods 30	D-Pods 40	D-Pods 50	Ridge 10	Ridge 20	Ridge 30	Ridge 60	Slider 10	Slider 20	Slider 30					
HP	Photosmart 318xi/320				•	•				•										•	•																							
	Photosmart 435				•	•				•										•	•																							
	Photosmart 620/720				•	•				•										•	•																							
	Photosmart 635				•	•				•										•	•																							
	Photosmart 735/735xi				•	•				•										•	•																							
	Photosmart 812				•	•				•										•	•																							
	Photosmart 850/850xi				•	•				•										•	•																							
	Photosmart 935/935xi				•	•				•										•	•																							
	Photosmart 945				•	•				•										•	•																							
	Photosmart C612/612xi				•	•				•										•	•																							
	Photosmart C618				•	•				•										•	•																							
	Photosmart E317			•	•	•			•	•									•	•																								
	Photosmart E327			•	•	•			•	•									•	•																								
	Photosmart M22/M23			•	•	•			•	•									•	•																								
	Photosmart M307/M407			•	•	•			•	•									•	•																								
	Photosmart M415			•	•	•			•	•									•	•																								
	Photosmart M417/M517			•	•	•			•	•									•	•																								
	Photosmart M425			•	•	•			•	•									•	•																								
	Photosmart M525			•	•	•			•	•									•	•																								
	Photosmart M527			•	•	•			•	•									•	•																								
	Photosmart R507		•	•	•	•		•	•	•									•	•																								
	Photosmart R607 SE		•	•	•	•		•	•	•									•	•																								
	Photosmart R707/R717		•	•	•	•		•	•	•									•	•																								
Photosmart R727		•	•	•	•		•	•	•									•	•																									
Photosmart R817			•	•	•		•	•	•									•	•																									
Photosmart R818			•	•	•		•	•	•									•	•																									
Photosmart R927			•	•	•		•	•	•									•	•																									
JVC	Everio GZ-MC100				•	•						•																																
	Everio GZ-MC200				•	•						•																																
	Everio GZ-MC500				•	•						•																																
	Everio GZ-MG27				•	•						•																																
	Everio GZ-MZ37				•	•						•																																
	Everio GZ-MZ77				•	•						•																																
	GC-QX3U				•	•						•										•																						
	GR-D200/D23/D53				•	•						•																																
	GR-D230				•	•						•																																
	GR-D240				•	•						•																																
	GR-D275				•	•						•																																
	GR-D295				•	•						•																																
	GR-D30/70/90US				•	•						•																																
	GR-DF430US				•	•						•																																
	GR-DVM76/96				•	•						•																																
	GR-DVP5/P7/P9				•	•						•																																
	GR-DX25/77/95/97				•	•						•																																
	GZ-M20/30/40/50				•	•						•																																

*Availability may vary by country or location

