

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Canon	DC-10	.				.									
	DC-100	.				.									
	DC-20	.				.									
	DC21/DC22	.				.									
	DC40	.				.									
	Elura 100	.				.									
	Elura 85	.				.									
	Elura 90	.				.									
	EOS 20D w/kit lens							.							
	EOS 30D w/small zoom							.	.	.					
	EOS 5D w/compact zoom				
	EOS Digital Rebel Xti/400D w/ compact zoom			
	EOS Rebel XT/350D with kit lens	
	ES420V/8200/8400V/8600				
	ES75			
	G30Hi/35Hi/45Hi											.	.	.	
	HV10		.												
	MV500/500i/550i/530i/600/600i/630i/650i		.												
	MV750i/730i/700i/700		.												
	MV800	.				.									
	MV830i	.				.									
	MV850i	.				.									
	MV890					.									
	MV900					.									
	MV930/940/950/960					.									
	MX100i/150i												.		
	MX1i		.												
	MX250i/200i/200	.										.			
	MX25i/20i		.									.			
	MX2i		.												
	MX330i	.				.									
	MX35i/30i		.												
	MX430					.									
	MX450/460					.									
	Optura 10/20												.	.	
	Optura 100MC	
	Optura 30/40	
	Optura 300/MVX10i	
	Optura 50		.			.									
	Optura 60		.			.									
	Optura 600		.			.									
	Optura Pi		.									.		.	
	Optura Xi/MV3Xi												.	.	.
	PowerShot G5	.												.	.
	PowerShot G6	.												.	.
	PowerShot Pro 1	.				.					.				
	PowerShot S2 IS	.				.					.				
	PowerShot S3 IS	.				.					.				
	V60Hi/65Hi/75Hi				.								.	.	
	VC-C4		
	ZR10/20/25/30/45MC	
	ZR100	.				.									.
	ZR200	.				.									.

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	ZR60/65MC/70MC		•												
	ZR80/85/90		•												
Epson	R-D1		•										•		
Fuji	FinePix F5 Pro w/compact zoom								•				•		
	FinePix S5600		•		•								•		
	FinePix S6000		•		•					•			•		
	FinePix S6500fd		•		•					•			•		
	FinePix S6900		•		•					•			•		
	FinePix S9000		•		•					•			•		
	FinePix S9100/9600		•		•					•			•		
	FinePix S9500		•		•					•			•		
Hitachi	DZ-BX37E		•												
	DZ-GX3100E		•		•										
	DZ-GX3200E		•		•										
	DZ-GX3300A		•												
	DZ-MV100A/ADO			•									•	•	•
	DZ-MV200		•										•		
	DZ-MV230		•										•		
	DZ-MV230A/270A/270E		•										•	•	
	DZ-MV380		•				•								
	DZ-MV550/MV580		•				•								
	DZ-MV730A		•		•										
	DZ-MV780A	•			•										
	M2L		•												
	VMD 865LA/VMH 665/675LA												•	•	
	VMD 875/975LA												•		
HP	Photosmart C618	•													

1=Best Fit, 2=Great Fit, 3=Fits

*Availability may vary by country or location

Updated 3/15/2007;Page 2 of 8

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
JVC	Everio GZ-MG26	•													
	Everio GZ-MG57EK					•									
	Everio GZ-MG77U	•				•									
	GD-D370	•				•									
	GR-AX970													•	
	GR-D200/D23/D53		•												
	GR-D20EK/D50EK		•										•		
	GR-D230	•													
	GR-D240					•									
	GR-D275					•									
	GR-D295					•									
	GR-D30/70/90US		•												
	GR-D33/72/93	•													
	GR-D350AA					•									
	GR-D650	•				•									
	GR-D72	•												•	
	GR-DF430US	•				•									
	GR-DV2000U													•	•
	GR-DV3000U/4000U													•	•
	GR-DV700/DV800U													•	•
	GR-DVL 160/DVL367	•						•					•		
	GR-DVL120U													•	•
	GR-DVL320/520/720				•									•	•
	GR-DVL725/767/820/920													•	•
	GR-DVM76/96	•												•	•
	GR-FX15EK/SX25/FXM39E/SXM49/SXM58													•	
	GR-SXM240/260/340/740													•	
	GR-X5			•			•							•	
	GR-XM250US/740U													•	
	GY-DV500US														•
	GZ-M20/30/40/50	•													
	GZ-M50S	•					•								
	GZ-MG26	•					•								
GZ-MG505HD	•					•									
JY-VS5200U													•	•	
Kodak	DX6490/7590/Z7590	•													
	Easyshare C875	•													
	Easyshare P712	•									•				
	Easyshare P850	•									•				
	Easyshare P880					•					•				
	Easyshare V603					•					•				
	Easyshare Z612										•				
	Easyshare Z650	•				•					•				
	Easyshare Z710	•				•					•				
Easyshare Z740	•				•					•					
Konica/Min	DiMAGE Z1 Thru Z3 and Z10	•				•					•				
	DiMAGE Z5/Z20		•			•					•				
	DiMAGE Z6		•			•					•				
	Dynax/Maxxum 5d w/short zoom					•	•					•			
	Maxxum/Dynax 7D w/short zoom									•			•		
Kvocera	M410R	•													
Leica	Digilux 2		•			•							•		
	Digilux 3		•			•							•	•	

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	M8 w/compact zoom			•			•						•		
	V-Lux 1			•			•						•		
Mustek	G-Smart 350	•													
Nikon	Coolpix 4500		•												
	Coolpix 5700/8700		•			•					•		•		
	Coolpix 8400	•				•					•				
	Coolpix 8800		•			•					•		•		
	D100 (Body only)		•										•		
	D200 w/compact zoom								•					•	
	D2x/D2h (Body only)			•									•		
	D40 w/compact zoom			•			•					•	•		
	D50 w/kit zoom			•			•					•	•		
	D70 w/kit zoom			•	•			•	•	•		•	•	•	
	D80 w/Compact Zoom			•	•			•	•	•		•	•	•	
Olympus	C-5060/C-7070 Wide Zoom	•				•									
	C-745/750/760/765 UZ	•				•									
	C-8080 Wide Zoom		•			•					•				
	D-370L/D-380	•													
	D-520	•													
	E-1 w/compact zoom			•	•	•						•		•	
	Evolt E-330 w/compact zoom			•			•					•	•		
	Evolt E-400 w/compact zoom			•			•					•	•		
	EVOLT E-500 w/compact zoom			•		•						•	•		
	EVOLT/E-300 w/14-45mm zoom			•			•					•	•		

1=Best Fit, 2=Great Fit, 3=Fits

*Availability may vary by country or location

Updated 3/15/2007;Page 4 of 8

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



	Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Panasonic AG-EZ50			•											•
DMC-FZ10/FZ10BB/FZ10BS		•			•							•		
DMC-FZ15/FZ20/FZ20BB		•			•					•		•		
DMC-FZ3/FZ3B/FZ4/FZ5	•				•					•		•		
DMC-FZ30		•				•					•			
DMC-FZ50		•				•					•			
DMC-FZ7	•				•					•				
DMC-LC1/LC1B		•			•							•		•
DMC-LC5	•													
Lumix DMC-L1 w/compact zoom				•		•					•	•		
NV-DS29														•
NV-EX21		•												
NV-GS1/GS4/GS5						•								
NV-GS11B/15B	•					•						•		
NV-GS120B/200B	•											•		
NV-GS180	•				•									
NV-GS250/400B				•									•	
NV-GS27	•				•									
NV-GS280		•												
NV-GS500			•		•									
NV-GS70	•													
NV-GX7		•				•						•		
NV-MX300B													•	
PalmCam PV-SD4090		•										•		
PV-DC152/252/352	•													•
PV-DV203	•											•		
PV-DV52/102/202/402				•									•	•
PV-DV702													•	•
PV-DV952			•									•	•	•
PV-GS120/200			•									•		
PV-GS150	•				•									
PV-GS19					•									
PV-GS250		•	•		•							•		
PV-GS300		•			•									
PV-GS31					•									
PV-GS35					•									
PV-GS400				•										
PV-GS500			•											
PV-GS50S												•		
PV-GS55					•									
PV-GS9/12/14/15	•													
PV-L352/452/552/652													•	
PV-L354/454													•	
PV-SD5000			•									•		
VDR-D250		•			•									
VDR-D300		•			•									
VDR-M30/M50/M50B/M70/M70B			•											
VDR-M53		•			•									
VDR-M75	•				•									

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Pentax	*ist D w/kit zoom				•			•				•			
	*ist DL w/kit zoom			•			•					•			
	*ist DS w/kit zoom			•			•					•	•		
	*st DS 2 w/kit zoom			•			•					•	•		
	EI-3000											•	•		
	K100D w/compact Zoom				•			•				•	•	•	
	K110D w/compact zoom				•			•				•	•	•	
Optio MX/MX4					•						•	•	•		
Polaroid	PhotoMAX PDC 700		•												
RCA	CDS4100		•												
	CDS6300		•												
Ricoh	Caplio 300G		•												
	Caplio 400G Wide		•												
	Caplio 500G Wide		•												
	Caplio G3/G4	•													
Rollei	d-24/d-30/d-530 Flex			•			•						•		
	Prego dk4010	•													
Samsung	Digimax Pro 815		•			•						•	•		
	GX-1L w/compact zoom			•		•						•	•	•	
	GX-1X w/compact zoom			•		•						•	•	•	
	SCD103/D107		•												
	SCD180		•												•
	SCD23/27/67/VP-D10			•									•	•	
	SCD353	•													
	SCD363	•													
	SCD590														•
	SCD6040 DuoCam		•												
	SCD6550 DuoCam	•					•								
	SCL610/650					•								•	
	SCL700/770, SCW62					•								•	
	SCL906					•								•	
	SC-X105L					•								•	
	VP-D10				•			•					•		
	VP-D101/D103				•			•					•		
	VP-D130		•					•							
	VP-D230/D270i			•			•								
	VP-D323/D325i							•							
	VP-D361i	•					•								
	VPD5000i		•						•				•		
	VP-D6040i/D6050i		•					•					•		
	VP-D80i					•			•					•	
	VP-D963 WI					•		•							
	VP-D97	•					•						•		
	VP-W90/VPL700/VPL900					•				•				•	
Sanvo	IDC-1000z		•									•			
Sharp	VL-AH161U/A111H												•		
	VL-AX1H/AX1U												•		
	VL-MC500H/500U		•									•			
	VL-NZ55U/105U		•									•		•	
	VL-Z1U/Z3U/Z5H/Z7U		•									•			
	VLZ900H		•				•					•			

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



	Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
Sony														
Alpha DSLR-A100 w/compact zoom				•			•				•	•	•	
CCD-TRV108/308/318/608														
CCD-TRV138			•		•							•		
CCD-TRV128/328												•		
DCR-DVD100/200/300		•												•
DCR-DVD101/201/301		•												
DCR-DVD105	•													
DCR-DVD203E		•			•									
DCR-DVD205/305	•													
DCR-DVD403E		•			•									
DCR-DVD405		•												
DCR-DVD505		•												
DCR-DVD605		•												
DCR-DVD705		•												
DCR-DVD92E	•				•									
DCR-HC1000/HC100D			•									•		•
DCR-HC14E	•					•								
DCR-HC21E					•									
DCR-HC42E					•									
DCR-HC65/85/85E	•											•	•	•
DCR-HC90E	•				•									
DCR-IP220		•										•		•
DCR-IP5/7BT														•
DCR-IP55	•													
DCR-PC1000E		•			•									
DCR-PC101/105	•													•
DCR-PC105E/106E/107E/109/109E	•													
DCR-PC110														•
DCR-PC120		•				•								
DCR-PC330		•												
DCR-PC350		•												
DCR-PC8	•					•								
DCR-SR100			•											
DCR-SR40	•				•									
DCR-TRV128/328			•								•			
DCR-TRV140												•		
DCR-TRV18/25/27			•									•		•
DCR-TRV19/22/33	•													
DCR-TRV240/340												•		
DCR-TRV250/350/450												•		
DCR-TRV260/265/460												•		
DCR-TRV280		•			•									
DCR-TRV38		•											•	•
DCR-TRV480		•			•						•			
DCR-TRV50/80		•										•		•
DCR-TRV530												•		
DCR-TRV740/840												•		
DCR-TRV950												•		
DSC-F828			•			•					•		•	
DSC-H1, H2, H5		•			•					•			•	
DSC-R1				•				•			•	•		
DSR-PDX10													•	
HDR-HC1								•					•	

1=Best Fit, 2=Great Fit, 3=Fits

LOWEPRO DIGITAL SHOULDER BAG MATRIX 2006



		Apex 100AW	Apex 110AW	Apex 120AW	Apex 140AW	Rezo 110AW	Rezo 120AW	Rezo 140AW	Rezo 160AW	Rezo 170AW	Rezo TLZ 10	Rezo TLZ 20	D-Res 40 AW	D-Res 50 AW	D-Res 240 AW
	HDR-HC3		•				•						•		
	HDR-SR1			•			•								
	HDR-UX1			•			•						•		
	MVC-CD350		•			•									
	MVC-CD500			•		•									
	MVC-FD200		•			•									
Thomson	VMD-160/170	•					•								
	VMD-270						•								
Toshiba	PDR-M700	•													
Vivitar	Vivicam V3500	•													

1=Best Fit, 2=Great Fit, 3=Fits

*Availability may vary by country or location

Updated 3/15/2007; Page 8 of 8